Тоуота GT Turbo.	COM Odometer miles/km:		
Engine & Drivetrain	Steering & Suspension		
		Engine Oil	3.5Ltr 5/10w-40
Replace Engine Oil & filter (Drain Bolt 25Nm)	Inspect Steering System Including Alignment Check by Road Test	Transmission Oil M/T	2.5Ltr 75w-90 GL5
Replace Manual/Automatic Transmission and Rear Differential Fluid	Inspect Front & Rear Suspension and Ball Joints	Transmission Oil A/T	5.5Ltr Dexron II or Dexron II
Drain and Replace Coolant	Inspect Front Wheel Bearings	Rear Differential Oil 4x4	1.45Ltr 75w-90 GL5
		Engine Coolant	Toyota 4Life
Replace Clutch Fluid	Inspect/Repack Rear wheel Bearings	Brake Fluid	Dot 5.1
Check and Top Up All Fluid Levels		Clutch Fluid	Dot 5.1
nspect Drive Shaft Boots	Chassis & Body	Powersteering Fluid	ATF Dexron II or Dexron II
Replace Spark Plugs (18Nm)	Inspect Tyre Condition & Tread Wear	Engine Oil Filter OEM p/n	90915-10003
	Approx. tread in mm: LHF RHF LHR RHR	Sump Plug Washer OEM p/n	
nspect Ignition Leads, Distributor Cap, Rotor Arm & Ignition Timing		Fuel Filter OEM p/n	23300-19395 NGK BKR6EIX or BKR7EI
Replace Fuel Filter	Set Tyre Pressures (Front-32psi Rear-30psi)	Distributor Cap OEM p/n	Boot Type 19101-11070
Inspect Air Filter (replace if using OEM filter)	Inspect Road Wheel Condition & Torque Wheel Nuts (103Nm)	Rotor Arm OEM p/n	Clip Type 19101-11080 19102-74040
Clean Throttle Plate (E.F.I.)	Inspect Exhaust Pipes and Mountings	Air Filter OEM p/n	17801-11050
		Timing Belt OEM p/n	13568-19106
nspect Camshaft Drive Belt (timing belt) Replace every 60,000 miles/105,000km or 5 years	Inspect Fuel Lines and Connections, Fuel Tank Vapour Vent System, Hoses and Fuel Tank Band	T/Belt Tensioner OEM p/n	13505-11040
nspect Condition of Hoses and Belts	Inspect Operation of Horn, Wipers, Washers, Lights, and Heater	T/Belt Idler OEM p/n	13503-11030
		Alternator Belt OEM p/n	90916-02341
Braking System	Lube All Locks, Latches, and Hinges	Powersteering Belt OEM p/n	90916-02366
Inspect Brake Pads/Shoes and Discs/Drums for condition and wear	Additional notes:		-
Approx. % of wear: LHF RHF LHR RHR			
Replace Brake Fluid			
Inspect/Adjust Parking brake Mechanism	to a state of the		